

3M™ REARVIEW MIRROR ADHESIVE

- Resistant to moisture, chemicals, vibration & impact
- Professionally mount rear view mirrors
- Excellent low temperature curing
- Flexible, excellent resistance to thermal cycles

DIRECTIONS FOR USE:

PREPARATION

- | | | |
|---|--|--------------------------|
| A | Mark original mirror button position on the OUTSIDE of the windshield using a marker or masking tape | <input type="checkbox"/> |
| B | Remove mirror from mounting button. Clean any remaining adhesive from glass and mounting button using 3M™ General Purpose Adhesive Cleaner (PN 08984) and 3M™ Glass Cleaner (PN 08888) | <input type="checkbox"/> |

ACCELERATOR/PRIMER

- | | | |
|---|--|--------------------------|
| C | Surfaces should be clean and dry | <input type="checkbox"/> |
| D | Remove the cardboard sleeve and place on the opposite end of the ampule, exposing the wick | <input type="checkbox"/> |
| E | Soak the wick by squeezing the sleeve to crush the ampule. Apply the primer to both the button and marked area of the windshield | <input type="checkbox"/> |
| F | Allow to dry for 5 minutes | <input type="checkbox"/> |

ADHESIVE

- | | | |
|---|--|--------------------------|
| G | Tear tab at the notch on the adhesive package | <input type="checkbox"/> |
| H | Squeeze the adhesive from the package and apply the mirror to the mounting button | <input type="checkbox"/> |
| I | Place the mirror button on the glass, rotate back and forth to thoroughly spread the adhesive on the glass | <input type="checkbox"/> |
| J | Hold in place securely without moving for one or two minutes | <input type="checkbox"/> |
| K | Allow one hour for the adhesive to set before reinstalling mirror on the button | <input type="checkbox"/> |



For more information on 3M Car Care products, visit www.3MCarCare.com or call (877) MMM-CARS

3Mcarcare.com